



Références de l'ensemble	Diamètre d'arbre	Symboles des roulements	Poids kg	Dimensions en mm											Charges	
				A	L	M	K	R	K1	B	B1	B2	C	P	dyn. C kN	stat. C0 kN
SFI 20	20	SA 204	0,45	52	112	61	11,5	90	30	31,0	36,0	26	12	12,5	12,8	6,6
SFIS 20		SB 204	0,42	52	112	61	11,5	90	30	25,0	30,5	26	12	12,5	12,8	6,6
SFI 25	25	SA 205	0,60	63	124	70	11,5	99	37,5	31,0	36,0	20	12	12,5	14,0	7,8
SFIS 25		SB 205	0,55	63	124	70	11,5	99	37,5	27,0	32,0	20	12	12,5	14,0	7,8
SFI 30	30	SA 206	0,80	65	142	80	11,5	117	40,0	35,7	42,7	31	14	16,0	19,5	11,3
SFIS 30		SB 206	0,75	65	142	80	11,5	117	40,0	30,0	38,0	31	14	16,0	19,5	11,3
SFI 35	35	SA 207	1,10	75	155	90	13,5	128	45,0	38,9	46,9	34	15	17,5	25,5	15,3
SFIS 35		SB 207	1,00	75	155	90	13,5	128	45,0	32,0	41,0	34	15	17,5	25,5	15,3
SFI 40	40	SA 208	1,20	85	170	100	13,5	142	55,0	43,7	51,7	36	16	19,0	32,5	19,8
SFIS 40		SB 208	1,10	85	170	100	13,5	142	55,0	34,0	44,0	36	16	19,0	32,5	19,8